



Safety instructions for external companies at the Lampoldshausen site



222

Emergency number (fire, accident, emergency): 222 (24 h)
Emergency number from external (mobile) telephones: +49 (0) 6298/28-222

Where has something happened? **Which** injuries?
What has happened? **Wait** for any questions!
How many persons are injured?

Conduct in event of a fire alarm:

Signal for a fire alarm: — — — 3 tones of 12-second duration

Get yourself to safety
Bring along helpless individuals

In case of an alarm or evacuation of buildings, go to the nearest assembly point immediately. Do not obstruct rescue work.
Roads must be kept clear for emergency services.



Conduct in event of a gas alarm:

Signal for a gas alarm:  wailing sound for 15 seconds

Stay in the building and close all windows and doors. If you are outdoors, leave the danger area in the direction crosswise to the wind direction, if possible.
Go to the nearest closed building.



All clear signal:

Signal for all-clear: ————— continuous sound for 15 seconds



Conduct at the location:

You are obliged to observe and follow the company-internal rules for work, fire and environmental protection.

Always wear your ID card so that it is visible.

Photography and filming is forbidden.

The grounds are monitored by CCTV.

Red traffic lights indicate a danger zone. The area may not be accessed.

A yellow flashing traffic light indicates an imminent danger in the immediate vicinity. Leave the area.

Red exit lights of the building indicate a danger zone.

Do not leave the building. A yellow flashing lamp indicates a danger zone nearby. You may leave the building with caution.

Areas cordoned off may not be accessed by foot or vehicle. Do not walk / drive through fluids, unknown solid substances or debris, dust or an escaping cloud of gas.

Electric, extinguishing and safety facilities as well as protective equipment may not be accessed, removed or deactivated without approval.


Loudspeaker announcements, such as for test notifications must be observed.

Instructions of the coordinator, the security centre, the site fire brigade or the site security services must be followed immediately.

Observe the escape and rescue plans on the notice board as well as the fire protection regulation notices.

There is a ban on take-off, flight and landing for manned/unmanned aircraft systems

The security centre can be reached at +49 6298 28-220



The road traffic regulations apply on the grounds:

The prescribed maximum speed is 30 km/h.

Parked vehicles may not block access to the safety facilities, impair the flow of traffic and only be parked at the allocated or marked parking places. Deployment areas for extinguishing and rescue measures must always be kept clear. Charging electric vehicles is only permitted at officially designated charging points.



Safety area:

Access to the testing and supply systems (test benches, tank farm, laboratories, etc.) is not permitted without approval. The respective safety markings must be observed!

Where necessary, wear the required protective equipment.

There is a strict smoking ban outside the smokers areas.

Vessels or systems with these or similar markings contain dangerous substances. When handling these, measures of the respective safety data sheets / operating instructions must be observed. Leaking damage and other environmental hazards must be reported to 222 immediately.

A written permit is required in advance for the following work:

- For working with dust as well as heat and fire
- Working in containers, pits and confined spaces
- Overriding hazard signalling devices
- Opening pipework
- Working in Ex zones

In areas with potential danger of explosions that are marked as such (yellow triangle with the black lettering "Ex"), devices that could represent an ignition source such as lighters and radio telephones may not be taken along nor used. Work to be carried out in an "Ex" protected area may only be carried out using work equipment that complies with the "Ex" protection guidelines ("ATEX").

